

Please use after reserves.

Call 7472 and tell the use time. (Sorry,Japanese only)

How to use of ultra centrifuge model XL-80

1. Adjust the balance of weight of sample. Set it in the rotor symmetrically
(When balancing, the weight of the cap and the bucket is included.)
2. The main body breaker is turned on. (The right side of main body)
3. The door is opened. The rotor is put on the axis.(Do not put a strain in the axis.)
The door is closed.
4. The [VACUUM] button is pushed, and the chamber is made a vacuum.
5. The [SPEED] button is pushed.
After the rotational speed is input, fixes it with [ENTER] button.
(Please push the [CE] button when you make a mistake in the input.)
6. The [TIME] button is pushed. After time is input, [ENTER] button is pushed.
(It counts down immediately after the start.)
7. The [TEMP] button is pushed. After temperature is input, [ENTER] button is pushed.
8. The [ROTOR] button is pushed.
After the number of the rotor is input, [ENTER] is pushed.
9. The [ACCEL PROFILES] button is pushed.
The degree of acceleration is selected. (Refer to a table)
(Please select 4 or 7 at the swing rotor use.)
10. The [DECEL PROFILES] button is pushed.
The degree of deceleration is selected. (Refer to a table)
(Please select 4 or 7 at the swing rotor use.)
11. When the value of vacuum becomes 750micron,
it is possible to start.
Push [START] button after pushing [ENTER] button
to start centrifuging

4 is used usually.

Number	Rotational speed	Arrival time
1	170	2:00
2	350	2:40
3	500	3:00
4	170	3:00
5	350	4:00
6	500	4:30
7	170	4:00
8	350	5:20
9	500	6:00

Additionally, "MAX SPEED"
and "NO BRAKE" can be selected.

After centrifugal finishes


12. The [VACUUM] button is pushed.
Air is enter in the chamber.
13. Open the door when the sound that air enters stops.
The rotor is taken out.
14. The main body breaker is turned off.

Please fill in the note after use.

Please wash the rotor, the bucket, and the cap
in distilled water.

When you want to set the temperature beforehand...

Make the chamber to the vacuum with the [VACUUM] button
after setting the temperature.



At the ACCEL 5 setting,
it will change into the maximum acceleration in 4min.
At the DECEL 5 setting,
it takes 4min from 350 to 0 rpm
after it decelerates by the maximum deceleration.